



RIDEA

— LHBD1 —



BIRDY

LAMP BRACKET FOR FRONT FORKS



USER MANUAL

www.rideabikes.com
service@rideabikes.com



Installation

1

- 1-1 Body
- 1-2 Washer
- 1-3 Set screw



2

- M3 screw for Ridea front suspension



PS. Original screw no need to be changed.

3

- Double-sided tape 44*15mm

Scale
(1:1)

Ⓐ 15*25mm

Ⓑ 10*19mm

1



2



Install lamp base and 1-2 to fit 1-1, and use 1-3 to screw together.

3



Cut out Part 3 to be suitable size according above image, and paste it to position A and B of Part 1.

A : 15*25mm

B : 10*19mm

Paste different side according Birdy model

C : Birdy 3

D : Birdy 2, New classic

Aim and stick the tape side on tapped hole, and screw tight suspension base and M3 together.